

**No:**

SB189-18

**Date:**

12/11/18

**Issue:**

1.

**Subject:**

Elite 6 Perceived Engine Oil Leaks within the Bell Housing Area

A small number of Elite 6 chassis have shown signs of oil leaks from the bell housing area as shown in the three images below.

Upon removal of the gearbox it was found the source to be a 'wax coating' applied to the gearbox torque converter. This wax coating is applied after manufacture to prevent oxidation during storage/transportation before fitment into the chassis.

It is recommended to clean this residue off by either steam cleaning or with brake cleaner.

