

No:

SB211-22

Date:

04/03/2022

Issue:

No.1

Subject:

eCollect Crash Sensor

If your eCollect shuts down in service and will not power back up after it has driven over a pothole or such like it is possible that the crash sensor has been triggered.

The sensor is located on the rear side of the air filter bracket, it is the red component shown within the yellow circle, this image is shown with the cab in the tilted position.

If the sensor has been triggered it will need to be reset, this is done by pushing down on the button, you will feel it engage and hold.

