

SERVICE BULLETIN

No:	SB229-24	Issue:	1
Date:	23/10/24	Sheet:	Page 1 of 1

SUBJECT: Putting Elite+ Electronic Park Brake (EPB) Into Workshop Mode

Workshop mode is used to disable the automatic function of the electronic park brake (EPB).

When workshop mode is activated the ignition can be switched off without the vehicle automatically applying the parking brake so that maintenance work can be carried out without the risk of automatic parking brake application.

Workshop mode can be activated with the following sequence:

- Stop the vehicle on a level surface and release the electronic parking brake (EPB) lever shown in Fig.1 below and leave the ignition on.
- Press the brake pedal.
- Push the EPB lever to the release position and switch off ignition with the brake pedal pressed and the EPB lever pushed.
- The vehicle is now in workshop mode.

Workshop mode can be disabled by either of the following methods:

- Apply the parking brake manually by pulling the EPB lever to the park position.
- Drive the vehicle over 10km/h.

Fig.1

